Lift Kit 35mm installation manual



Front axel

- 1. Disassemble the front shock
- 2. Disassemble the spring
- 3. Add the 35 mm spacer at first



- 4. Cut the bump stop 10 mm (first ring)5. Assemble the shock





Rear axel:

- 1. Disassemble the rear shock
- 2. Disassemble the spring
- 3. Add the 40 mm spacer at first



- 4. Cut the bump stop 20 mm (on the black ring)
- 5. Assemble the shock
- 6. Open and close all rubber bearing to avoid any tension on the axel link



Finished