



Position	Part number	Name
1	164000001	Switch lever
2	164000002	Upper handle
3	164000003	Outer cover of support
4	164000004	Spring
5	164000005	Left holder
6	164000006	Pin
7	164000007	Fast-locking lever
9	164000009	Handle bolt
10	164000010	Lower handle
11	164000011	Inner cover of support
14	164000014	Switch inner box
17	164000017	Plug
18	164000018	Plug pressing board
22	164000022	Switch
23	164000023	Right holder
24	164000024	Button spring
25	164000025	Switch button
26	164000026	Switch outer box
27	164000027	Spring
28	164000028	Cable hook
31	164000031	Rear board axle
32	164000032	Rear board
33	164000033	Rear board spring
35	164000035	Right bracket of lower handle
37	164000037	Knob bolt
44	164000044	Rear wheel axle
46	164000046	Left bracket of lower handle
48	164000048	Handle upper part
49	164000049	Handle lower part
50	164000050	Height adjustment lever
51	164000051	Spring
52	164000052	Height adjustment rod
53	164000053	Wheel bearing
54	164000054	Rear wheel
55	164000055	Rear wheel cover
56	164000056	Front wheel cover
57	164000057	Front wheel
58	164000058	Height adjustment board
60	164000060	Blade holder - Fan
61	164000061	Blade
62	164000062	Blade screw
63	164000063	Front wheel axle
64	164000064	Front axle support
65	164000065	Front axle clip
68	164000068	Motor base
69	164000069	Capacitor
70	164000070	Motor
72	164000072	Motor upper base
74	164000074	Motor upper cover
77	164000077	Grasscatcher frame
78	164000078	Grasscatcher bag