

SOFT SHELL ROOFTOP TENT



- ❑ A packed wet tent should **ALWAYS** be out and dried completely.
- ❑ **NEVER** use fire inside or near a roof tent.
- ❑ Always have a fire extinguisher nearby.
- ❑ Never block the exit.
- ❑ Max speed: 115km / h - Max weight in tent: 300kg
- ❑ It is **YOUR** responsibility that your car / roof racks are suitable for the roof tent.

Share your photos with us

Welcome to QingDao New Sunda
Hope you enjoy the view

Installation guide:

- 1. Carefully unpack the tent from the packaging. Open the tent slightly and remove the bag with mounting parts.**



- 2. Check that all mounting parts are in the bag. (Note tools not included and not required)**



- 3. Lift the roof tent securely up on your roof racks. This task requires 2 people.**



- 4. Insert the bolt through the plate. Check that this is facing correctly.**

Then insert 2 bolts / plates into each end of the aluminum rail at all 4 ends.

Lift the roof tent slightly at each end and slide 1 piece onto it
other side of your roof racks, so you have 1 bolt / plate on each side of the roof rails.



5. Arrange that the roof tent has the desired location on the roof and the roof hangers so that it is centered.

**Insert the steel plate over the bolts.
Fit thumbscrews and tighten.**



NOTE / Important:

**Tighten the thumbscrews after 1 day as well check regularly that they are securely fastened.
Before using the tent, it must be watered 1-2 times with a garden hose from the outside.
This is then all the threads in the seams "raises / swells", which makes the seams tight.**

User Manual:

6. Hang the ladder on the top of the tent.



7. Pull the ladder.



8. Open the velcro and button around the tent.



9. Pull out the ladder fully.



10. Push the ladder down as far as possible. In this way, lift the tent up perpendicularly.



11. Pull the ladder so that the bottom moves in your direction.



12. Adjust the ladder in height. This is done at the top, with the small clamps.



13. Fit all rods to stretch the fabric.



14. Secure two elastic ropes



NOTE:

When collecting the tent,remove all the stainless steel support rods and put them inside the tent.

Closure is performed in reverse order.

A packed wet tent should always be out and dried completely.

15.Open the expansion ladder completely.



16.Hold the bottom of the ladder and lift the ladder forcefully so that the top of the ladder moves towards the tent.



17.Retract the ladder completely.



18.Tuck the exposed fabric around into the roof tent.



19.Close the button and stick the velcro.

