

SSC-LUXon GmbH - Am Krozinger Weg 4, 79189 Bad Krozingen, Germany E-Mail: service@ssc-luxon.de; Phone: +49 7633 - 988 3000

Assembly/operating instructions for SSC-LUXon recessed light RW-2 & QW-2

1. Intended use

This product is for lighting purposes only and: -may only be mounted radiating downwards -can be installed indoors and outdoors -protection type IP44, suitable for use in damp areas -must not be exposed to strong mechanical loads or heavy soiling -may not be operated after damp or dirty storage until after a condition check -may not be changed or modified, otherwise the operating permit and conformity will expire with immediate effect! It is not allowed to remove the type plate.

▲ If the aforementioned points are not observed, a short circuit or electric shock may occur! There is danger to life!

2. General safety instructions

▲ The complete installation may only be carried out by an authorized electrician who is familiar with the applicable guidelines. Hereinafter referred to as "qualified electrician".

A For safe handling of the product, the user must have read and understood the installation/operating instructions completely before using the device for the first time.

▲ The product may only be used if it is alright. If the device or parts of it are defective, it must be repaired by a qualified electrician.

▲ Only use lamps/light source approved by the manufacturer. The max. lamp wattage in watts is not allowed be exceeded.

▲ This product is not a toy and is not allowed be stored or used within the reach of children.

▲ Safe operation of the product is only guaranteed if these instructions are followed. Therefore, keep these assembly/operating instructions. SSC-LUXon GmbH accepts no liability if the instructions given here are not followed or the lamp is subjected to improper use.

3. Assembly & configuration

A Caution: The connecting cable must be disconnected from the power supply before starting work (switch off the main switch/fuse)! Only use parts which are supplied with the product or which are clearly marked as equipment! Otherwise the product may not be sufficiently safe!

▲ The cable routing shown in the illustrations is for simplified purposes only. They in no way represent a recommendation for connection! The connection may only be carried out by a qualified electrician.

▲ When drilling, pay attention to cables and gas and water lines. Always route the cable so that it does not touch the luminaire. Fig.5.2

4. Operation, bulb replacement, faults & disorders

▲ Never look directly into the light source!

Replacement of lamps/light sources:

▲ Caution: Disconnect the connecting cable from the power supply before replacing lamps/light sources!

Halogen lamps/light sources become very hot during operation - risk of burns! Therefore, do not touch the protective glass or the reflector! Allow to cool down before replacing! Do not cover! There is a risk of fire when covering (e.g. with towel)! Lamps with protective cover may only be operated with complete protective cover!

What to do in case of error?

In case of an error, the device must be switched off immediately. The product may only be operated if it works correctly. The device may only be put back into operation after it has been checked by a qualified electrician! This is the case if:

1. there is visible damage, 2. the product is not working corrctly, 3. there is smoke, steam, or audible crackling noises, 4. overheating can be detected

A Caution: There is a danger to life - repairs to the product or work on parts carrying mains voltage may only be carried out by qualified electricians

Avoidance of disturbances and fire hazards:

It is not allowed to cover the product under any circumstances. Air circulation must be ensured. Nothing may be attached or hung on the product, especially no decoration.

5. Cleaning & care instructions

The product may only be wiped dry or carefully with a slightly damp and lint-free cloth. The product is not allowed to be removed for this purpose. Do not use abrasive or sharp objects or aggressive cleaning agents. Do not use solvents.

Technical data model RW-2





outdoors

Type:	Recessed light round
Model:	RW-2
Protection type:	IP44
Voltage:	12V DC oder 230V AC
Material:	Aluminium
Measurements:	Ø 85 mm
Cutout:	57 - 75 mm
Installation depth incl. light source:	65 mm
Distance floor-ceiling:	12V: no default / 230V: mind. 2,25m
Swivel range:	Non swivelling
Max. watt light source:	35 W

Technical data model QW-2





Can be used indoors and outdoors

Type:	Recessed light square
Model:	QW-2
Protection type:	IP44
Voltage:	12V DC oder 230V AC
Material:	Aluminium
Measurements:	90 x 90 mm
Cutout:	57 - 80 mm
Installation depth incl. light source:	65 mm
Distance floor-ceiling:	12V: no default / 230V: mind. 2,25m
Swivel range:	Non swivelling
Max. watt light source:	35 W

6. Assembly instructions

- 1. Disconnect the connecting cable from the power supply!
- 2. Measure and cut out the cutout (Ø see technical data). Fig.1.1
- 3. Press out the inner ring with the glass pane from behind (the springs point in your direction) with both thumbs. Fig.1
- 4. Insert the light source into the recessed light from the front and connect the connecting cable with the mains cable. Fig.2
- 5. If halogen lamps are used, they may be used with a maximum of
- 6. Push the spring clips upwards and insert the lamp into the cutout. Fig.3.a + b
- 7. Suitable for ceilings 3-20mm thick. Fig.4
- 8. Make sure that the product cannot fall down after assembly! The product is now ready for use.

7. General & notes



Disconnect the device from the mains power before starting anv work



Protection class II



Do not cover with insulating material



Installation only by qualified electrician



Distance to illuminated objects min 0.5m





▲ Protection type IP20 & IP23: Use only

indoors and dry, i.e. do not use in damp or

dirty rooms and in areas of high humidity.

A Protection type IP44 & IP65: Can be used



Satisfied with your product? Then we look forward to your product review in our online store, on Amazon or eBay!

www.led-lichtraum.de



Make sure to dispose packaging in accordance with the applicable guidelines of your local authority. Devices marked with the crossed-out waste garbage do not belong in the household waste! You are obliged to hand

in these devices at one of the free collection points in your municipality. You can obtain more information from your local authority, the relevant town hall or a local or regional waste disposal company.

▲ Keep packaging material and small parts away from children and animals. Danger of suffocation!

Vers. 03/2019



SSC-LUXon GmbH - Am Krozinger Weg 4, 79189 Bad Krozingen, Germany E-Mail: service@ssc-luxon.de; Phone: +49 7633 - 988 3000

